

# di SKALA G310

# **COMMUNICATIONS**

Model **G** is capable of communicating with other scales of the same series, with a computer o with a TPV.

It has an 9-way female RS-232 connector on the bottom with electrical connections as follows:

RxD	pin2
TxD	pin3
GND	pin5

If the scales are connected to a PC, the latter may have a 9 or 25 way connector, with the following description:

Description	DB 9 ( PC 9)	DB 25 ( PC 25)
Display	-	1
TXD (data sent)	3	2
RXD ( data received )	2	3
RTS	7	4
CTS	8	5
DSR	6	6
Mass	5	7
CD	1	8
DTR	4	20
RI	9	22

The following connections should be made:

Scales	DB 9	Scales	DB 25
2	2	2	3
3	3	3	2
5	5	5	7

Never use a communications cable different to the one shown above.

#### 1. PROGRAMMING OF COMMUNICATIONS

#### 1.1. Communication characteristics

For programming of communications, the process is as follows:





**3.** Select the type of communication in accordance with the table below:

Туре	Bauds	Data Bits	Stop Bits	Parity
0	9600	8	1	No
1	9600	8	1	Even
2	9600	8	1	Odd
3	9600	8	2	No
4	9600	7	1	Even
5	9600	7	1	Odd
6	9600	7	2	Even
7	9600	7	2	Odd
8	19200	8	1	No
9	19200	8	1	Even
10	19200	8	1	Odd
11	19200	8	2	No
12	19200	7	1	Even
13	19200	7	1	Odd
14	19200	7	2	Even
15	19200	7	2	Odd
16	4800	8	1	No
17	4800	8	1	Even
18	4800	8	1	Odd
10	4800	Q	2	No

and 🔼

C

Туре	Bauds	Data Bits	Stop Bits	Parity
20	4800	7	1	Even
21	4800	7	1	Odd
22	4800	7	2	Even
23	4800	7	2	Odd
24	2400	8	1	No
25	2400	8	1	Even
26	2400	8	1	Odd
27	2400	8	2	No
28	2400	7	1	Even
29	2400	7	1	Odd
30	2400	7	2	Even
31	2400	7	2	Odd
32	1200	8	1	No
33	1200	8	1	Even
34	1200	8	1	Odd
35	1200	8	2	No
36	1200	7	1	Even
37	1200	7	1	Odd
38	1200	7	2	Even
39	1200	7	2	Odd

Having selected the type of communication, press 🛃 to save it and then select the protocol.

# 2. COMMUNICATION PROTOCOLS

Once the communications parameters have been programmed, the scale will show in the display the possibility of selection of the communications of protocol. Depending on the model, the scale will have the possibility of storing only one protocol or several (until a maximum of 60) protocols.



**NOTE:** In scales G-310 the protocol used must be loaded from PC. In scales G-320 all the protocols are programmed in the scale.

Enter the selected protocol number according to Table 1

1. Press (the machine waits until the software of the PC sending the protocols starts to run).

Code	Protocol	Code	Protocol
1	ANKER	18	TISA con envío en peso Stable
2	TPV CASIO	19	VD TISA
3	RIVA / UNIWELL	20	VD SEUR
4	TISA	21	UNIPROX con 6 dígitos de precio
5	EAN a PC ICL	22	STAR (con envío en peso Stable)
6	SANYO	23	
7	APOLLO/SAMSUNG POLONIA	24	Checkout_Dialog06
8	DELTA	25	EUROSTAR 2000T ALPHA
9	ALFA	26	
10	DOLAR/SAMSUNG ESPAÑA	27	DATECS
11	SAMSUNG PORTUGAL	28	TPV CASIO NUEVO
12	UNIPROX (BMC PS-2000)	29	
13	UNIPROX con checksum	30	
14	SHARP UP-700	31	ELZAB
15	KABEL (ITALIA)	32	TOWA
16	NCI	33	SHARP UP-700-2
17	ECR-POSNET		


Table 1

# 2.1. Characteristics of the protocols

Protocol	Parameter	Protocol	Parameter
1-ANKER	0	8-DELTA	1
2-CASIO CE at 9600	4	9-ALFA	1
2-CASIO CE at 2400	24	10-SAMSUNG ESPAÑA	0
3-RIVA	2	11-SAMSUNG PORTUGAL	4
3-UNIWELL	28	12-UNIPROX	0
4-TISA	0	12-BMC PS2000	4
5-EAN at PC ICL	1	13-UNIPROX (with checksum)	0
6-SANYO	5	14-SHARP UP700	29
7-APOLLO/SAMSUNG POLONIA	0	15-KABEL	0
7-POSTNET POLONIA	0	16-NCI	-

# 2.2. Operation


Having configured the type of device with which communication is to be established, simply effect the desired operation from the corresponding TPV, and the scales will automatically send the weight message.



# 3. PROTOCOLS TYPE


# 3.1. ANKER cash register protocol

#### **Protocol**




# 3.2. TPV CASIO CE protocol

#### **Protocol**




# 3.3. RIVA / UNIWELL cash register protocol

#### **Protocol**




# 3.4. TISA cash register protocol

#### **Protocol**




# 3.5. EAN cash register protocol to PC ICL

## **Protocol**




# 3.6. SANYO cash register protocol

#### **Protocol**




# 3.7. APOLLO/SAMSUNG POLAND / POSNET POLAND cash register protocol

#### **Protocol**




# 3.8. DELTA cash register protocol

#### **Protocol**




# 3.9. ALFA cash register protocol

#### **Protocol**




# 3.10. SAMSUNG-SPAIN cash register protocol

#### **Protocol**



# 4.3.11. SAMSUNG PORTUGAL cash register protocol Protocol



W: 0X57H, Weight request.

**C**<sub>R</sub>: 0x0Dh **L**<sub>F</sub>: 0x0Ah


WWWWWW: 5 digits for WEIGHT..: 0x2E. Decimal point.S: 0x53h. Weight status.

**00:** 0x30h, 0x30h. Whether correct weight status is activated.

**KG**: 0x4Bh y 0x47h


**E**<sub>TX</sub>: 0x03h

# 3.12. UNIPROX / BMC PS 2000 cash register protocol Protocol




**Note:** the WEIGHT-PRICE-SUM is not a protocol for the scales. WEIGHT-PLU CODE is, however, a protocol and therefore the keys in all the other protocols can be used to enter the product price, and thus calculate the sum. In this protocol, the PLU code to be sent to the cash register is determined. The row for the sum is cancelled in this protocol.

# 3.13. UNIPROX with CHECKSUM cash register protocol Protocol




# 3.14. SHARP UP-700 cash register protocol

#### **Protocol**




Using the different heading, the protocol is developed in the same way for all three sets



Note: the sharp up 700 is not a protocol for the "only weight" scales

# 3.15. KABEL cash register protocol

#### **Protocol**



The weight is sent by pressing the ENTER key. The weight cancellation command can be sent by pressing the key on the scales, and in this mode the characters is sent by pressing the c key on the cash register (0x63h).

# 3.16. NCI cash register protocol


#### **Protocol**

Cash Register


V C<sub>R</sub>

L<sub>F</sub> xx.xxx Kg C<sub>R</sub> L<sub>F</sub> S<sub>H</sub> C<sub>R</sub> E<sub>X</sub>

2) Status request




# 3) Zero setting of the scale




#### 4) Command unknown

In case of not sending any of the previous commands, the scale answer "Command unknown"




# 3.17 Protocol ECR-POSNET)



Note: X is a space (0x20h).

**Note:** In case of quantities with value < 1000 the positions on the left are filled with "0" (0x30h) but in case of quantities > 1000 these positions are filled with " " (0x20h).

# 3.18 Protocol TISA (with sending of stable weight)




**Note:** Once the weight is received, the scale sends the data when the weight is stable, it is not negative and there is not error.

#### 3.19 Protocol VD TISA


#### **Protocol**

Cash Register Scale




**Note:** The scale sends the data when the weight is stable, it is not negative, it is bigger than 0 and there is not error





**Note:** The scale sends the data when the weight is stable, it is not negative, it is bigger than 0 and there is not error


# 3.21 Protocol UNIPROX (with 6 digits for price)



**Note:** The Scale sends the data when the key Enter is pressed.

# 3.22 Protocol STAR (with sending of stable weight)

#### **Protocol**



Note: The X is the character space (0x20h).


3.23 Reserved

#### 3.24 Protocol DIALOG 06


#### **Protocol**

There are four different strings

String 1



From the 4 different string the protocol function as follows



WWWWW: 5 digits for weight
PPPPPP: 6 digits for PRICE
IIIII: 6 digits for AMOUNT
TTTT: 4 digits for the PLU tare

**MMMMMMMMMMMMM:** 13 digits for the PLU description ( ignored by the scale)

#### Protocol EUROSTAR 2000T ALPHA 3.25

#### **Protocol**

# Cash Register Scale $E_{q}$ $\mathsf{A}_\mathsf{K}$ $D_{1} \\$ $S_HS_xSXWW.WWWkgB_{cc}E_xE_T$

#### Where:

0x05h 0x11h 0x06h Eq: A<sub>K</sub>: D<sub>1</sub>: S<sub>H</sub>: 0x01h S<sub>x</sub>: 0x02h S:

Weight Status

S: 0x53h Stable. S: 0x55h UnStable.

X: 0x20h

wwww: 5 digits for weight 0x2Eh 0x6Bh y 0x67h kg:

B<sub>cc</sub>: Checksum,(XOR) from S of weight status.

0x03h E<sub>x</sub>: 0x04h E<sub>T</sub>:


Note: The character X is the character space (0x20h).

#### 3.26 Reserved

#### **Protocol DATECS** 3.27

#### **Protocol**

Cash Register Scale



N<sub>L</sub>: GGG: 0x00h S<sub>x</sub>: 0x02h


3 digits for grams

KKK: 3 digits for kilograms

PPPPP: 5 digits for price IIIIII: 6 digits for amount

Note: The scale will allways send zeroes (0x30) in the digits of price and amount.

#### **Protocol**




#### 3.29 Reserved

# 3.30 Protocol DIALOG 06 (with minimum weight)

## **Protocol**

It is possible to send 4 different strings

String 1



Where:			
E <sub>T</sub> :	0x04h		
S <sub>x</sub> :	0x02h		
A <sub>K</sub> :	0x06h		
E <sub>c</sub> :	0x1Bh		
Eq:	0x05h		
0:	0x30h	1:	0x31h
2:	0x32h	3:	0x33h
4:	0x34h	5:	0x35h
wwww:	5 digits for WEIGHT		
PPPPPP:	6 digits for PRICE		
IIIII:	6 digits for AMOUNT		
TTTT:	4 digits for the PLU tare		


Note: The different between this protocol and protocol number 24 is that for this protocol the scale does not send an error message when the weight is under minimum weight of the scale(20\*e).

#### **Protocol ELZAB** 3.31


#### **Protocol**

There are two types of strings

String 1



From the headers, the protocol will follow the same for both strings




Note: The X represent the character space (0x20h).

#### **Protocolo**


#### 1.Command mode:

There are three possible formats depending on the string send by the Cash register:

#### FORMAT 1




#### FORMAT 2



 ${\rm S_{X}}$  S SIGN W5 W4 W3 W2 W1 W0 UN1 UN0 BCC  ${\rm E_{X}}$  $\mathrm{S}_{\mathrm{X}}$  U7 U6 U5 U4 U3 U2 U1 U0 BCC  $\mathrm{E}_{\mathrm{X}}$   $\mathrm{E}_{\mathrm{T}}$ 

#### FORMATO 3



 $\mathrm{S}_{\mathrm{X}}$  U7 U6 U5 U4 U3 U2 U1 U0 BCC  $\mathrm{E}_{\mathrm{X}}$   $\mathrm{E}_{\mathrm{T}}$ 

Note: In format 3 the scale will send the data continuously once per second.

#### 2.Key trigger mode:

When the key ENTER is pressed in the scale:

 Cash Register
 Scale

 S<sub>X</sub> 41h 32h M4 M3 M2 M1 M0 P5 P4 P3 P2 P1 P0 C E<sub>X</sub>

When the keys SHIFT and TOTAL are pressed in the scale

# Cash Register Scale S<sub>H</sub> S<sub>X</sub> P7 P6 P5 P4 P3 P2 P1 P0 BCC E<sub>X</sub> S<sub>X</sub> S SIGN W5 W4 W3 W2 W1 W0 UN1 UN0 BCC E<sub>X</sub> S<sub>X</sub> U7 U6 U5 U4 U3 U2 U1 U0 BCC E<sub>X</sub> E<sub>T</sub> Where: S<sub>H</sub>: 0x01h E<sub>X</sub>: 0x03

S<sub>X</sub>: 0x02h E<sub>T</sub>: 0x04 0x05h 0x06h Ea:  $A_k$ : Stable: 0x53h UnStable: 0x55h S: 0x2Dh SIGN: 0x20h +: 0x20h UN1:

UN1: g: 0x20h UN0: g: 0x67h

BCC: Exclusive value of the data block.

C: Check point.

 $M_4M_3M_2M_1M_0$ : PLU Code. It is 99999 when PLU is not used.


 $\begin{array}{ll} W_5W_4W_3W_2W_1\ W_0: & \text{6 digits for WEIGHT.} \\ P_7P_6P_5P_4P_3P_2P_1P_0: & \text{8 digits for AMOUNT.} \\ U_7U_6U_5U_4U_3U_2U_1U_0: & \text{8 digits for PRICE.} \end{array}$ 


## 3.33 Protocol SHARP UP-700-2

## **Protocol**

There are three possible strings

String 1





E <sub>T</sub> :	0x04h
S <sub>x</sub> :	0x02h
A <sub>K</sub> :	0x06h
Ec:	0x1Bh
E <sub>Q</sub> :	0x05h

 0:
 0x30h
 1:
 0x31h

 2:
 0x32h
 3:
 0x33h

WWWWW: 5 digits for weight

PPPPP: 6 digits for PRICE

IIIII: 6 digits for AMOUNT

TTTT: 4 digits for the PLU tare

MMMMMMMMMMMM: 13 digits for the PLU description ( ignored by the scale)

#### 3.34 Protocol QT-6000

#### **Protocolo**

There are 4 possible strings.

String 1

Cash Register Scale

String 2

Cash Register Scale

String 3

Cash Register Scale


E<sub>T</sub>S<sub>X</sub>04E<sub>C</sub>PPPPPE<sub>C</sub>MMMMMMMMMMMMMMME<sub>X</sub>

String 4

Cash Register Scale

 $E_{T}S_{X}0\underbrace{5E_{C}PPPPE_{C}TTTTE_{C}MMMMMMMMMMMMM}_{\textbf{E}_{X}}E_{X}$ 

From the initial strings, the protocol is the same



**WWWWW:** 5 digits for weight **PPPP:** 6 digits for PRICE


IIIII: 6 digits for AMOUNT
TTTT: 4 digits for the PLU tare

MMMMMMMMMMMM: 13 digits for the PLU description ( ignored by the scale)

#### 3.35 Protocol OLIVETTI

#### **Protocol**

Cash Register Scale



#### Where:

**d:** 0x64h

**2**: 0x32h 8: 0x38h

**0**: 0x30h


**WWWWW:** 5 digits for PRICE

K: XOR de los dígitos anteriores

 $\mathbf{C}_{R}$ : 0x0Dh  $\mathbf{L}_{F}$ : 0x0Ah

#### 

#### **Protocol**



The Scale sends the  $\mathbf{E}_{\mathbf{Q}}$  when the key Enter is pressed.

## Where:

 Eq:
 0x05h

 Ak:
 0x06h

 Sx:
 0x02h

**WWWWWW:** 6 digits for weight.

**E**<sub>x</sub>: 0x03h